

# Mini RollDown - Cheat Sheet

MODE	Functions	DMX ch.	Function
1	Positioning with slow ramp	1	Position rough (Hi of a 16 bit DMX channel)
2	Positioning with medium ramp	2	Position fine (Lo of a 16 bit DMX channel)
3	Positioning with fast ramp	3	Set the maximum speed
4	Positioning with slow ramp limits active	4	60-65% <i>Save soft limits</i> Enabled
5	Positioning with medium ramp limits active		Else <i>Save soft limits</i> Disabled
6	Positioning with fast ramp limits active	5	Find top position, moving up
0,7,8,9	Neutral function - motor stops	6	Set soft BOTTOM limit

## Before each use



- Inspect the **Mini Roll Down** for damage, wear, corrosion or abuse.
- Inspect the **fabric/curtain attachment** for damage, wear, corrosion or abuse and secure the fabric/curtain is safely attached and weighs max 7 kg.
- Check all limit switches.
- Check that the **Mini Roll Down** is securely mounted according to the user manual.

**Warning! Do not use the Mini Roll Down if any damage or error is found!**

# How to get started

1. Put on fabric/curtain on the tube.
2. Apply DMX from a Lighting desk, best is a desk with manual faders.
3. Make sure that your six channels are patched from DMX channel 1 to 6.
4. Pull all channels on to 0%
5. Apply power to the Mini Roll Down and set the address to 001 and the mode to 1 - DMX lamp should be lit.
6. Set DMX channel 4 to 63% - This enables the saving of top and bottom position.
7. Pull channel 5 to 20 % -- the Mini Roll Down starts moving up.  
Stop the Mini Roll Down (pull channel 5 to 0%) when the desired top position is reached.
8. Pull channel 6 to 20 % -- the Mini Roll Down starts moving down.
9. Stop the Mini Roll Down (pull channel 6 to 0%) when the desired bottom position is reached.
10. Pull channel 1 (position) to 75 %
11. Pull channel 3 (speed) to 50% - The Mini Roll Down start to move up, with 50% speed, to a position that is 75% up.
12. Pull channel 1 (position) to 25% - The Mini Roll Down starts to move down, with 50% speed, to a position that is 25% up.

## Green LED indicators:

LED next to the DMX-selectors.

Glows constant: DMX connection is correct.

Flash: DMX signal is missing.

LED next to the DMX-selectors.

Fast flashing: The roll down needs to be reset, before it can be used.

Slow flashing: The roll down's is moving towards the set position

Steady light: The set position has been reached and the motor stopped.

## Tech specs:

Lifting speed Variable 2.5-26 cm/s (1.0-10.2 in/s)

Maximum load 7.0 kg (15.4 lb)